



Que ponta de aparafusadora usar

www.leroymerlin.pt

Tipos de pontas



Ponta plana



0,5x3
0,6x4
0,8x5,5
1x6
1,8x6,5

Ø 2-2,2mm
Ø 2,5-2,9mm
Ø 2,9-3,5mm
Ø 4mm
Ø 5mm

Ponta phillips



Nº 0
Nº 1
Nº 2
Nº 3

Ø 1,6-2mm
Ø 2,5-3mm
Ø 3,5-5mm
Ø 5,5-7mm


Ponta hexagonal



3mm
4mm
5mm
6mm

Ø 4-5mm
Ø 5-6mm
Ø 6-8mm
Ø 8-10mm

Ponta pozidriv



Nº 0
Nº 1
Nº 2
Nº 3
Nº 4

Ø 1,6-2mm
Ø 2,5-3mm
Ø 3,5-5mm
Ø 5,5-7mm
Ø 8-10mm


Ponta torx



Nº 10
Nº 15
Nº 20
Nº 25
Nº 30
Nº 40

Ø 3-3,5mm
Ø 3,5-3,9mm
Ø 4-4,2mm
Ø 4,8-5mm
Ø 6-7mm
Ø 8mm

Casquilho e adaptador



Nº 8
Nº 10
Nº 13

Ø 5mm
Ø 6mm
Ø 12mm